
Congratulations with your purchase and the choice for



KOALA CREEK® AWNINGS

Adventurer 140 x 200 cm. (rear)

Adventurer 140 x 200 cm. (rear)

Explorerer 200 x 250 cm. (side)

Explorerer 250 x 250 cm. (side)

Explorerer 250 x 250 cm. (side)

VEHICLE AWNING INSTRUCTIONS



INSTALLATION PARTS

MOUNTING INSTRUCTIONS

OPERATING INSTRUCTIONS

CAUTIONS

WARRANTY

KOALA CREEK® AWNINGS

INSTALLATION PARTS:

 AWNING X1	 PEG x2	 ROPE x2	 STAINLESS STEEL BOLT X4
 "L" BRACKET x2	 "T" SCREW x4	 WRENCH x1	 INSTRUCTION x1

MOUNTING INSTRUCTIONS:

1. FOR THIS INSTRUCTION YOUR VEHICLE NEEDS TO HAVE 2x VERTICAL ALLOY ROOF BARS. THESE ALLOY ROOFBARS HAVE A 20 MM T-SLOT. IF NOT, PLEASE ASK A DEALER OR A CAR MECHANIC FOR HELP WHEN NEEDED.



2. SLIDE 2x "T" SCREWS INTO EACH OF THE 2 ROOF BARS, PUT ON THE "L" BRACKET, AND BOLTED TOGETHER WITH "T" SCREWS.



3. SLIDE THE 4x BOLTS INTO THE BACK SIDE MOUNTING EXTRUSION OF THE AWNING, WHICH CAN HOLD THE HEAD OF THE BOLTS CAPTIVE.



4. PUT THE BOLTS TO A PROPER POSITION, BOLTED THE AWNING AND "L" BRACKET TOGETHER

5. MOUNTING FINISHED AFTER ALL 8xBOLTS FIXED.



CHECK CORRECT MOUNTING AFTER FIRST 100 KM.
CHECK CORRECT MOUNTING DURING EACH TRIP.

KOALA CREEK® AWNINGS

OPERATION INSTRUCTIONS

1. OPEN THE OUTER BUCKLES ON THE COVER, UNZIP THE COVER AND UNFASTEN THE VELCRO INSIDE.



2. UNROLL THE AWNING FROM THE ALUMINUM EXTRUSION, MEANTIME, SWING OUT THE BOTH ARMS.



3. RELEASE THE 2 LEGS FROM THE INSIDE OF THE FRONT BEAM, ADJUST THEM INTO A PROPER HEIGHT YOU NEED BY REVOLVING THE POLE (BUT NOT REVOLVE THE BLACK PLASTIC CONNECTION) AND LOCKED.



4. EXTENDING THE ARM TO CONNECT THE FRONT BEAM BY INSERTING THE END PIN INTO THE CORRESPONDING HOLE. ADJUSTING IT TO A CORRECT LENGTH BY REVOLVING THE ARM AND LOCKED. OPERATION FINISHED AFTER FIXING ALL THE VELCRO TABS AND PEGGED THE 2 ROPES..



5. SIMPLY REVERSE OF ABOVE PROCEDURES TO PACK UP THE AWNING.

6. FOR A GOOD WATERFLOW ON THE AWNING SET UP WITH ABOUT 5 -10 CM HEIGHT DIFFERENCE BETWEEN 2 FRONT BEAMS.

7. USE THE SUPPLIED ROPES AND PEGS TO SECURE AWNING TO THE GROUND.

KOALA CREEK® AWNINGS

CAUTIONS:

- PLEASE INSTALL YOUR AWNING COMPLETELY ACCORDING TO INSTRUCTIONS.
- ALWAYS SECURE THE AWNING WITH PEGS AND ROPES.
- IN RAINY DAY, ENSURE THE AWNING WAS SET UP TO APPROPRIATE ANGLE TO ALLOW RAIN WATER TO RUN OFF.
- DO NOT STORE THE AWNING WET FOR LONG TIME, IT ONLY CAN BE STORED AWAY WET FOR LIMITED PERIODS, BUT HAVE TO BE OPENED AND ALLOWED TO DRY AS SOON AS POSSIBLE.

WARRANTY AND CONDITION

- ANY ONE AWNING WAS BACKED UP 24 MONTH WARRANTY, EFFECTIVE FROM DATE OF PURCHASE.
- THE FAULT OCCURS UNDER NORMAL CIRCUMSTANCES WHERE THE AWNING HAS BEEN USED IN ACCORDANCE WITH THE INSTRUCTIONS SET OUT IN THIS GUIDER
- THE FAULT IS FOUND TO BE CAUSED BY DEFECTIVE OR FAULTY MATERIAS, WORKMANSHIP OR MANUFACTURING PROCESS.
- ORIGINAL PROOF AND DATE OF PURCHASE MUST BE PROVIDED.
- CLAIMS OTHER THAN THE ABOVE ARE NOT COVERED BY WARRANTY, RESERVES THE RIGHT TO REPAIR OR REPLACE AT OUR DISCRETION.

- In case of question please ask your preferred Koala Creek® dealer.
- KOALA CREEK® is a registered trade brand owned by TWISTIM, Outdoor in motion.

TWISTIM, Outdoor in motion.
Gadestraat 3
6165CH Geleen
The Netherlands
www.koalacreek.info



**KOALA
CREEK**